



BUNDUANNEX

Mounting hardware/Requirements:

- 1 x measuring tape
- 1 x 5mm drill bit
- 1 x Rivet tool
- 1 x bag with rivets (supplied)
- 1 x silicone tube

Procedure:

- Place 2m rope guide on BunduTop roof, flat section towards the tent.
- Measure 10mm from roof plate and extrusion joint.
- Drill 5mm holes through the extrusion. Take care to not drill through the roof lining.
- You can use a pipe or tube socket as a spacer to drill the holes.
- Place a small dab of silicone around the holes.
- Place long rope guide on roof and rivet with sealed rivets.
Place short rope guide, stopper to the back and flat piece to the top, on top of the bottom corner rivet on the small side of the tent. Mark holes.



- Drill 5mm holes through the extrusion.
- Place short rope guide over holes and rivet with the sealed rivets.
- Drill a 5mm hole directly above the middle rivet.
- **Revit flange rivit with 6mm nut.**
- Repeat process on other side.
- **Spray Q20, WD40 or any other thin film lubricating spray down the length of the rope guide .**
- Place Added Room bag rope in the rope guide and pull through.
- Take care to keep Added Room level. This will ensure the rope enters the guide easily.
- Tie knot into rope to keep Added Room in place.

Refer to Added Room user manual for operating instructions.